


PARTS LIST

Item	Model 206	Model 209	Part Number	Part Name
A	×	×	H-1150	Control Wheel
B	×	×	H-1273	Stem
C	×	×	H-1152	Feed pipe
D	×	×	H-1322	Burner Assembly
E	×	×	H-1336	Tank Assembly
F	×	×	H-1332	Check Valve
G	×	×	H-1233	U-cup
H	×	×	H-1231	Pump Complete
I	×	×	H-1333	Cap
J	×	×	H-2162	Grate
K	×	—	H-1057	Lid Stay
L	×	—	H-1276	Lid Complete
M	×	—	H-1064	Bushing
N	—	×	H-1743	Hole Cover
O	×		H-1193	Spring Lock



PARTS LIST FOR BURNER

ITEM	PART NO.	PART NAME
1	1414	Burner Body Assembly
2	1123	Valve w/Washer, Packing & Nut
3	240-149	Cleaning Needle
4	1117	Nozzle
5	1128	Inner Cap
6	1127	Outer Cap
7	141-107	Filter
8	2307	Copper Washer
2300		Burner renewal kit consists of items 2-8 above and complete instructions.

← BURNER FLANGE

← BURNER BODY